



QUICK REFERENCE PREVENTATIVE MAINTENANCE INTERVAL CHART

Cycle	Description
Daily	Inspect Hydraulic Components – Cylinders, PTO, Valve, etc.
Daily	Inspect for Hydraulic and Air Leaks
Daily	Check Hydraulic Oil Level
Daily	Check Structural Components and Welds
Daily	Inspect Front and Rear Container Stops and Hold Down
Daily	Inspect Cable Sheaves and Pins
Daily	Inspect Rear Hinge Assembly
Daily	Inspect Container Rollers
Daily	Inspect Pull Cable – Anchors and End
Daily	Inspect all Body Lights
Daily	Check Back up and Hoist Alarms
Weekly	Grease all Fittings (40) Hours of Operation
Every 3 Months	Inspect condition of Hydraulic Oil – color, odor and feel
Every 6 Months	Replace Hydraulic Filter
Every 6 Months	Replace Air Breather
Every 12 Months	Replace Hydraulic Filter and Air Breather
Every 12 Months	Replace Hydraulic Fluid – AW32
Every 12 Months	Clean Suction Strainer

These inspections are intended to verify that the hoist and its components are in the proper safe operation and are within normal wear guidelines. If these are any items that do not pass your inspection, you must notify your supervisor and a “lockout tag” must be placed on the equipment.